

Lab 6 - Solution

November 13, 2019

1 Lab 6 - Solution

In this lab we will, as a class, create the grading script for the final project.

```
In [1]: import librosa
import numpy as np
import sys
import pickle
import time
import IPython.display as ipd
from codec import encode, decode
```

1.1 Import Audio File

Load in an audio file to test with codec.

```
In [2]: def load_cd_quality_audio(filename):
        audio, sr = librosa.load(filename, sr = 44100, dtype='float_')
        max_int_value = 2**15 - 1
        audio *= max_int_value
        audio = audio.astype('int16')
        return audio

x = load_cd_quality_audio("taxman.wav")
```

1.2 Runtime

Encode and decode the audio. Time the processes.

```
In [3]: encodeStartTime = time.time()
        x_encoded = encode(x)
        ert = time.time() - encodeStartTime

        decodeStartTime = time.time()
        x_decoded = decode(x_encoded)
        drt = time.time() - decodeStartTime
```

1.3 Format Check

Check to make sure the decoded audio is mono 16 bit.

```
In [4]: def check_decoded_output(d):
        if type(d) != np.ndarray:
            print('ERROR: Your decoded signal is not a numpy array!')
        elif d.dtype != 'int16':
            print('ERROR: Your decoded signal does not contain 16 bit integers!')
        elif len(d.shape) != 1:
            print('ERROR: Your signal is not a 1-dimensional vector!')
        else:
            print('Your decoded signal passes the format check.')

        check_decoded_output(x_decoded)
```

Your decoded signal passes the format check.

1.4 Compression Ratio

Compare the sizes of the original and encoded structures.

```
In [5]: def compressionRatio(original, encoded):
        o_str = pickle.dumps(original)
        e_str = pickle.dumps(encoded)
        return sys.getsizeof(o_str)/sys.getsizeof(e_str)

        cr = compressionRatio(x, x_encoded)
```

1.5 SNR

Compare the original signal content to the decoded version

```
In [6]: def signalToNoise(original, decoded):

        original = original.astype('float_')
        decoded = decoded.astype('float_')

        # force the signals to be the same length
        diff = len(original) - len(decoded)
        if diff < 0:
            decoded = decoded[:diff]
```

```

elif diff > 0:
    decoded = np.append(decoded, np.zeros( (diff,1) ) )

    # compute snr
    signal = np.power(original,2)
    noise = np.power(original - decoded,2)

    signal = np.where(signal == 0, np.finfo(np.float32).eps, signal)
    noise = np.where(noise == 0, np.finfo(np.float32).eps, noise)

    return np.mean(10 * np.log10(signal/noise))

snr = signalToNoise(x, x_decoded)

```

1.6 Evaluate Codec

Print out evaluation of codec. Listen to the results

```

In [7]: print("Compression Ratio: ", str(round(cr,4)))
        print()
        print("Total Runtime: ", str(round(ert + drt,4)))
        print("\tEncode Runtime: ", str(round(ert,4)))
        print("\tDecode Runtime: ", str(round(drt,4)))
        print()
        print("SNR: ", str(round(snr,4)))

```

Compression Ratio: 1.0

Total Runtime: 0.0001

Encode Runtime: 0.0001

Decode Runtime: 0.0

SNR: 135.3601

```

In [8]: # Original
        ipd.Audio(x, rate = 44100)

```

Out[8]: <IPython.lib.display.Audio object>

```

In [9]: # Decoded
        ipd.Audio(x_decoded, rate = 44100)

```

Out[9]: <IPython.lib.display.Audio object>